


# ELECTRIC CLRCUIT DIAGRAM



START SWITCH			HORN SWITCH			FRONT LIGHT SWITCHES					MAIN SWITCH				TURNING SWITCH			DIMMER SWITCH			
	Y/R	G		B	B/R	BY	Y	Lg	W	P	B	B/W	G	R	L	R/G	Lg	B			
OFF			OFF			OFF					LOCK										
ON	○	○	ON	○	○	(N)	○	○	○	○	OFF	○	○	○	○	○	○	○			
						(N)	○	○	○	○	ON				HIGH BEAM						
						(N)	○	○	○	○					PASSING						
						(N)	○	○	○	○					LOW BEAM						
						(N)	○	○	○	○											

COLOUR INDICATION:  
 Y. YELLOW Z. PURPLE Y/R. YELLOW-RED LW. BLUE/WHITE B. BLACK  
 LB. LIGHT BLUE Y/B. YELLOW-BROWN B. BROWN G/Y. GREEN-YELLOW  
 G. GREEN B/R. BROWN-RED P. PINK L. BLUE R/G. RED-BROWN  
 B/W. BROWN-WHITE G. GREY Lg. LIGHT GREEN R. RED O. ORANGE  
 B/R. BLACK-RED R/W. RED-WHITE B/W. BLACK-WHITE GB. GREEN-BLACK